

CONGRATULATIONS ON YOUR NEW STAND MIXER PURCHASE

For assistance call KitchenAid at **1-800-541-6390**

IMPORTANT INFORMATION YOU NEED TO KNOW

1. IF BEATER HITS BOWL UPON FIRST USE

- a. See user manual for “Adjusting Beater to Bowl Clearance”.
- b. Make sure the back of the Bowl is securely snapped into the neck of the Stand Mixer.

2. IF PRODUCT EMITS UNUSUAL ODOR UPON INITIAL USE

- a. New electrical motors will often emit an odor upon initial use. This is normal.

3. IF PRODUCT SHUTS OFF AFTER EXTENSIVE USE

- a. Motor has automatic sensor that will keep motor from overheating by shutting it off. If this occurs, let Stand Mixer rest for 20 minutes before restarting.

4. IF TOP OF MIXER FEELS WARM TO TOUCH AFTER EXTENSIVE USE

- a. After use, it is normal for the motor to heat up and feel uncomfortable to the touch.

****Important: Please do not return product to store****

For assistance call KitchenAid at **1-800-541-6390**
or visit us at **WWW.KITCHENAID.COM**

— — — — —

FÉLICITATIONS POUR VOTRE NOUVEAU MÉLANGEUR SUR SOCLE

Pour obtenir de l'aide, contacter KitchenAid au **1-800-807-6777**

INFORMATIONS IMPORTANTES

1. SI LE BATTEUR HEURTE LE BOL LORS DE SA PREMIÈRE UTILISATION

- a. Voir "Ajustement du dégagement entre le mélangeur et le bol" dans le manuel d'utilisation.
- b. S'assurer que l'arrière du bol est bien emboîté dans le col du mélangeur sur socle.

2. SI LE PRODUIT ÉMET UNE ODEUR INHABITUELLE LORS DE LA PREMIÈRE UTILISATION

- a. Les moteurs électriques neufs émettent une odeur lors de leur première utilisation. Ceci est normal.

3. SI LE PRODUIT S'ÉTEINT APRÈS UNE UTILISATION PROLONGÉE

- a. Le moteur comporte un capteur automatique qui coupe le moteur pour l'empêcher de surchauffer. Si cela se produit, laisser s'écouler 20 minutes avant de remettre le mélangeur sur socle en marche.

4. SI LE DESSUS DU MÉLANGEUR EST CHAUD AU TOUCHER APRÈS UNE UTILISATION PROLONGÉE

- a. Après utilisation, il est normal que le moteur chauffe et que cette partie de l'appareil soit désagréable au toucher.

****Important : Ne pas rapporter le produit au magasin****

**Pour obtenir de l'aide,
contacter KitchenAid au 1-800-807-6777
ou consulter notre site Web WWW.KITCHENAID.CA**