

**KitchenAid®**


**UNDERCOUNTER DISHWASHER**

**MODELS:**

KDPE234GPS0 (Stainless)

KDPE234GBS0 (Black Stainless)


# DOOR AND PANEL PARTS



# DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4	W10273971	Screw	9	W10858692	Cover, Display Lens
	W10806906	Installation Instructions	5		Access Panel	10	W10073520	Insulation, Door
	W10909170	Energy Guide		W10526114	Black	11	W10692757	Barrel Nut, Front Panel
	W11040103	Use & Care Guide	6		Front Panel (Includes Item 11)	12	302868	Screw (Black)
	W10904612	Tech Sheet		W11024140	Stainless	13	3400071	Screw
2		Arm, Hinge		W10878067	Black Stainless	14		Fastener
	8534854	Left Hand	7	W10858705	Cover, Handle Pocket		W10503548	Black
	8534853	Right Hand	8	W10518815	Insulation, Four Layer			
3	W10844384	Barrier, Vapor						


# CONTROL PANEL AND LATCH PARTS



# CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)	3	W10825638	Box, Connector	6	W10913971	Control, Electronic
	W10905151	Black	4	W10348408	Screw	7	W10825369	Brace, Connector
2	W10899392	Jumper, 4-Wire	5	W10653840	Latch Assembly (Includes Switch)	8	W10889948	Jumper, 3-Wire

# INNER DOOR PARTS




# INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw
2	8281217	Screw
3	W10712597	Inner Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10667473	Seal, Door Bottom
5	W10889942	Wiring Harness

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10620296	Dispenser Assembly
7	W11050927	Seal, Console/Door


# FILL, DRAIN AND OVERFILL PARTS



# FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch	7	W10327250	Fill Valve Assembly	13	W10195036	Float & Retainer Assembly
2	W10769066	Inlet, Hose	8	3390631	Screw	14	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
3	W10195536	Inlet, Water (Also Order Item 4)	9	W10734532	Switch, Overfill Control			
4	8531323	Gasket	10	W10647205	Housing, Overfill (Also Order Item 11)	15	370445	Clamp, Hose
5	W10213825	Nut, Water Inlet (Also Order Item 4)	11	8531743	Gasket, Flat	16	W10545278	Drain loop with check valve assembly
6	371505	Clamp, Hose	12	W10195038	Nut, Standpipe			


# TUB AND FRAME PARTS



# TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10681491	Tub Assembly (Also Includes Heater Assembly)	13	W10681564	Support Assembly, Rear	24	W10866978	Shield, Tub Sound
2	W10713315	Assembly, Terminal Box	14	W10348411	Screw	25	W10300703	Bracket, Thermostat
3	W10660528	Gasket, Tub	15	W10190778	Wheel Leg	26	W10195091	Thermostat
4	W10813122	Plug, Tub	16	W10619352	Leveler, Leg	27	W10819539	Sound Insulation, Bottom
5	W10544004	Strike, Latch	17	3378128	Washer, Pronged Cup	28	W10696509	Heater Element Assembly
6	304392	Screw	18	8270020	Spring, Door Balance			(Includes Heater Washer & Nut)
7	W10835073	Seal, Cabinet	19	3400014	Screw, Grounding			NOTE: If heater element is removed, it must be replaced.
8	W10337661	Strain Relief	20	W10653292	Cover, Terminal Box			
9	W10084086	Door Balance Assembly	21	W10158291	Cable, Door			
10	3367670	Screw	22	W10292870	Shield, Thermostat			
11	8269145	Bracket, Undercounter	23		Spacer, Tub/Brace			
12	3400074	Screw		W10195630	Left Hand			
				W10195631	Right Hand			


# PUMP, WASHARM AND MOTOR PARTS



# PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10854710	Motor (Also Order Items 9 & 11)	7	W10858786	Wash Arm Assembly	14	W10724439	Pump, Drain
2	W10195086	Motor, Isolator	8	W10789806	Filter Cup Assembly	15	8269144	Hose, Drain
3	W10455271	Cover, Outlet	9	W10445975	Hose Assembly (Includes 2 Clamps)	16	W10476221	Disc, Diverter
4	W10455268	Sump With Seal (Also Order Items 9 & 11)	10	W10917110	Sump & Motor Assembly	17	W10849439	Motor, Diverter
5	9741232	Screw	11	W10538166	Grommet	18	8269146	Clamp, Hose
6	W10463906	Screen	12	W10348407	Screw	19	W10723295	Indicator, Optical Wash
			13	W10372113	Tab, Sump	20	W10789434	Clamp, Hose
						21	W10350335	Damper, Sump Assembly


# UPPER WASH AND RINSE PARTS



# UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10340745	Feed Tube Assembly (Includes Items 2 & 3)	2	W10327455	Sprayarm, Third Level	4	W10340542	Manifold
			3	3400918	Retainer	5	W10448645	Sprayarm, Upper
						6	W10195690	Bracket, Feed Tube


# UPPER RACK AND TRACK PARTS



# UPPER RACK AND TRACK PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10312792	Dishrack, Upper	4	W10546503	Adjuster Assembly	10		Track, Assembly
2		Housing, Adjuster (Includes Spring and Lever)	5	W10195839	Strap, Tether Adjuster		W10914015	Left Hand
	W10588164	Left Hand	6	W10195840	Positioner, Adjuster		W10914016	Right Hand
	W10588165	Right Hand	7	W10309090	Screw	11	W10778309	Handle, Dishrack Front
3	W10250160	Clip, Adjuster	8	W10752617	Clip, Dispenser Guard	12	W10473792	Handle, Dishrack Rear
			9	W10250162	Cover, Adjuster	13	9741232	Screw


# LOWER RACK PARTS



# LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525641	Dishrack, Lower	3	W10473836	Basket Assembly, Silverware
2	W10195416	Wheel & Transport Assembly	4	W10473835	Lid, Silverware Basket

# THIRD LEVEL RACK AND TRACK PARTS



# THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Track Assembly
	W10653357	Left Hand
	W10653356	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10309090	Screw
3	W10653326	Rack, Third Level

# OPTIONAL PARTS (NOT INCLUDED)

## ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		TOWEL BAR HANDLE
W10701399		Stainless
		DISHRACK ACCESSORIES
W10712311		Anti-Tarnish Silverware Basket
W10712312		Cutlery Dishwasher Basket
W10712313		Bottle/Vase Holder
		DRAIN HOSE
W10712310		12 Ft.
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
4396853		Silver Atlantis
		MOISTURE BARRIER KIT
4396277		Barrier Kit

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	4396603	Meteorite

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

## POWER CORD KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

## ANTI-TIP KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

## DISHRACK REPAIR

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis