KitchenAid®

7 QT. STAND MIXER
PROLINE - BOWL LIFT


MODELS:

KSM7586PCA1 (Candy Apple)
KSM7586PFP1 (Frosted Pearl)
KSM7586PMS1 (Medallion Silver)
KSM7586PMZ1 (Merlot)
KSM7586POB1 (Onyx Black)
KSM7586PSR1 (Sugar Pearl)

02/01/2019

Part No. W10544196 Rev. C


COLOR VARIATION PARTS



COLOR VARIATION PARTS

Illus. No.	Part No.	Description
1		Motor Housing
	W10403016	Candy Apple
	W10454050	Frosted Pearl
	W10354887	Medallion Silver
	W10602466	Merlot
	9705296	Onyx Black
	W10520271	Sugar Pearl
2		Trim Band
	W10234515	Dark Platinum
3		Lower Gearcase
	W10403006	Candy Apple
	W10454060	Frosted Pearl
	W10354882	Medallion Silver
	W10602458	Merlot
	W10410015	Onyx Black
	W10520261	Sugar Pearl
4		Planetary
	W10403008	Candy Apple
	W10520287	Frosted Pearl
	W10354883	Medallion Silver
	W10602459	Merlot
	W10410018	Onyx Black
	W10520266	Sugar Pearl
5		Bowl Support and Pins
	W10402998	Candy Apple
	W10448659	Frosted Pearl
	W10354878	Medallion Silver
	W10602454	Merlot
	9705356	Onyx Black
	W10520248	Sugar Pearl
6		Column and Pins
	W10402992	Candy Apple
	W10520203	Frosted Pearl
	W10354872	Medallion Silver
	W10602450	Merlot
	9705320	Onyx Black
	W10520205	Sugar Pearl
7		Base and Foot Assembly
	W10402986	Candy Apple
	W10448638	Frosted Pearl
	W10354860	Medallion Silver
	W10602446	Merlot
	9705344	Onyx Black
	W10520258	Sugar Pearl


CASE, GEARING AND PLANETARY UNIT



CASE, GEARING AND PLANETARY UNIT

Illus. No.	Part No.	Description
1		Gearcase Motor Housing
		(Refer to Color Variation Parts Page)
2	W10394928	Cap, Attachment Hub, Hinged
3		Band, Trim
		(Refer to Color Variation Parts Page)
4	W10351843	Screw
5	W10305968	Holder, Control
6		Lower Gearcase
		(Refer to Color Variation Parts Page)
7	W10234493	Gear, Ring and Plate Assembly
8	3400617	Screw
9	3400814	Screw
10	W10517938	Motor, 120 Volt Assembly
11	3400200	Screw
12	W10545635	Control Assembly, 120 Volt
13	W10234531	Pin, Groove
14		Cord, Power
	W11197466	Black
	W11197467	White
15		Planetary Assembly
		(Refer to Color Variation Parts Page)
16	9703438	Ring, Retaining
17	9706090	Washer
18	W10234643	Gear, Pinion
19	9707223	Pin, Retaining
20	8533910	Washer
21	9708191	Shaft, Agitator
22	9703680	Clip, Retaining
23		Thumb Screw
	W10512907	Chrome
24	9704677	Pin, Groove

BASE AND PEDESTAL UNIT



BASE AND PEDESTAL UNIT

Illus. No.	Part No.	Description
1		Literature Parts
	W10728463	Use and Care Guide
2	W10617049	Shield, Pouring (Wide)
3	W10354778	Bowl, 7 Qt.
4	240185	Pin, Retaining Bowl
5	W10504114	Clip, Bowl Retainer
6	3400018	Screw
7		Bowl Support (Refer to Color Variation Parts Page)
8		Base and Foot Assembly (Refer to Color Variation Parts Page)
9	9708649	Foot
10	9703307	Ring, Retaining
11	W10598835	Rod, Bowl Lift
12	9237	Spring, Lift Rod
13	9703439	Washer
14	8533907	Nut
15		Column Assembly (Refer to Color Variation Parts Page)
16	W10672613	Beater, Flat
17	W10674615	Hook, Dough (7 Quart)
18	9706885	Arm, Bowl Lift
19	W10600940	Whip, Wire
20	9703426	Cam, Adjusting
21	3400863	Screw
22	W10598836	Handle, Bowl Lift
23	W10511912	Cap, Handle
24	3400200	Screw