KitchenAid®

7 QT. STAND MIXER
UNITED KINGDOM


MODELS:

5KSM7591XBER0 (Empire Red)
5KSM7591XBSL0 (Silver)
5KSM7591XBSM0 (Silver Metallic)
5KSM7591XBWH0 (White)

01/07/2020

Part No. W10463001 Rev. C


COLOR VARIATION PARTS



COLOR VARIATION PARTS

Illus. No.	Part No.	Description
1		Motor Housing
	9703311	White
	9705300	Empire Red
	W10454049	Silver Metallic
	9709571	Silver
2		Trim Band
	W10419455	Dark Platinum
3		Lower Gearcase
	W10234488	White
	W10410011	Empire Red
	W10450993	Silver Metallic
	W10234491	Silver
4		Planetary
	W10420628	White
	W10419426	Empire Red
	W10452357	Silver Metallic
	W11407815	Silver
5		Bowl Support and Pins
	9703674	White
	9705360	Empire Red
	W10448648	Silver Metallic
	W10327840	Silver
6		Column and Pins
	W10451002	White
	W10451578	Empire Red
	W10451113	Silver Metallic
	W11407807	Silver
7		Base and Foot Assembly
	9703690	White
	9705348	Empire Red
	W10448633	Silver Metallic
	9709588	Silver


CASE, GEARING AND PLANETARY UNIT PARTS



CASE, GEARING AND PLANETARY UNIT PARTS

Illus. No.	Part No.	Description
1		Gearcase Motor Housing (Refer to Color Variation Parts Page)
2	W10395280	Cap, Attachment Hub (Satin Chrome)
3		Band, Trim (Refer to Color Variation Parts Page)
4	W10351843	Screw
5	W10305968	Holder, Control
6		Lower Gearcase (Refer to Color Variation Parts Page)
7	W10234493	Gear, Ring and Plate Assembly
8	3400617	Screw
9	3400814	Screw
10	W10517943	Motor & Transmission Assembly (230 Volt)
11	3400200	Screw
12	W11178568	Control Assembly (230 Volt)
13	W10234531	Pin, Groove
14		Cord, Power
	W10459179	White (United Kingdom)
	W10419451	Black (United Kingdom)
15		Planetary Assembly (Refer to Color Variation Parts Page)
16	9703438	Ring, Retaining
17	9706090	Washer
18	W10234643	Gear, Pinion
19	9707223	Pin, Retaining
20	8533910	Washer
21	9708191	Shaft, Agitator
22	9703680	Clip, Retaining
23		Thumb Screw
	W10360791	Black
24	9704677	Pin, Groove
25	W10417201	Clip, Plug
26	W10703125	RFI Filter

BASE AND PEDESTAL UNIT PARTS



BASE AND PEDESTAL UNIT PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W11356007	Use & Care Guide
2	W10617049	Shield, Pouring (Wide)
3	W10354780	Bowl, 7 Qt.
4	240185	Pin, Retaining Bowl
5	W10504114	Clip, Bowl Retainer
6	3400018	Screw
7		Bowl Support
		(Refer to Color Variation Parts Page)
8		Base and Foot Assembly
		(Refer to Color Variation Parts Page)
9	9708649	Foot
10	9703307	Ring, Retaining
11	W10598835	Rod, Bowl Lift
12	9237	Spring, Lift Rod
13	9703439	Washer
14	8533907	Nut
15		Column Assembly
		(Refer to Color Variation Parts Page)
16	W10672613	Beater, Flat
17	W10674615	Hook, Dough (7 Quart)
18	9706885	Arm, Bowl Lift
19	W10600940	Whip, Wire
20	9703426	Cam, Adjusting
21	3400863	Screw
22	W10598836	Handle, Bowl Lift
23	W10391115	Cap, Handle
24	3400200	Screw
25	9706814	Screen, Vent